

Mixturus

MIXTURUS DRY FLOWER/HERB, CONCENTRATE, CARTRIDGE VAPORIZER

Congratulations—you've made a powerful choice. Mixturus isn't just a vaporizer; it's a statement. Engineered as a sleek, 3-in-1 device, it was created for those who defy convention, embrace creativity, and elevate every herbal session into a personal ritual.

Rite Innovations was born from a spark between two friends who believed the herb ritual could become an art form. Founded in Benton Harbor, Michigan, we stand for empowerment, inclusion, and innovation. We design tools that break stigmas and invite you to live life on your terms.

With intuitive features, adaptable design, and premium craftsmanship, Mixturus transforms each draw into a note in your own symphony of flavor and intention. This guide will help you unlock its full potential and get the most from your experience.


Welcome to Rite Innovations—a movement for seekers, creators, and everyday adventurers.
Your Rite. Your Journey. Your Creation.

TABLE OF CONTENTS

Page	
1	Welcome
2	Device Overview
3	Safety Precautions
4	Quick Start Guide
5-6	User Guide
7-8	Dry Flower/Herb Chamber
9	Concentrate Chamber
10-11	510 Cartridge adapter
12-13	Tips and Tricks
14	Maintenance/Cleaning
15-17	Troubleshooting/Warranty/Service
18-19	Exploring Vapable Herbs
20	Warranties

DEVICE OVERVIEW

- 1. Ergonomically Designed Device / Food Grade Rubber Mouthpieces
 - a. Upper and Lower
 - b. 304 Stainless Steel Screen
 - c. Cotton Filter
- 2. Power/Control Button
- 3. Color LED Temperature Display
- 4. Charging Pad with Cord
- 5. Dry Flower/Herb Chamber
- 6. Concentrate Chamber
- 7. 510 Cartridge Adapter
- 8. Alcohol Infused Cotton Swabs
- 9. Travel Pouch
- 10. Rechargeable Battery
- 11. Multi Tool
- 12. Cleaning Brush



1a



1b



1c




8

9



10



1



6



7

11



5



4



12



SAFETY PRECAUTIONS

Avoid water or humidity exposure.



Chambers will be hot directly after use and should be allowed to cool down for at least 5 minutes before handling.



Never throw this or other lithium-ion batteries in the trash or incinerator. Properly recycle/dispose as per local regulations.



Only use alternative dried herbs in the Mixturus listed on page 25 which have been tested for authenticity by the FDA, European Pharmacopoeia (or similar agency). Inhaling others can be potentially dangerous.



The Mixturus is not intended for the use of tobacco or other nicotine products.




For safety and energy efficiency, device automatically shuts off after 60 seconds of no air movement during a session or 10 minutes of inactivity, LED lights will flash 5 times



5x


QUICK START GUIDE

Fully charge device using the provided charging base and cord until all LED lights are solid green




Assemble the Mixturus based on the chosen chamber. Switching between chambers is easy with the help of a magnetic connection which helps chamber click into place

Turn Unit on by clicking the Power/Control Button with 5 rapid clicks



428°F
410°F
392°F
365°F
338°F


Burn-off: Select temperature/voltage based on chamber being used by clicking the power/control button 2 times to cycle through settings to the highest temperature



600°F
550°F
500°F
450°F
400°F

Burn-off session: Take a short puff to begin heating process and immediately set device down to complete burn-off cycle

Once device turns off automatically, burn-off cycle is complete and you can repeat the puff at a different temperature to enjoy normally




3.7V
3.2V
2.7V
2.2V
1.8V

Experiment with temperature/voltage settings to find your perfect match for chambers/adaptor

USER GUIDE

Before using for the 1st time:


After assembling your Mixturus with your desired chamber for the first time, for the best experience on your 1st use, we recommend performing a full session burn cycle




To power on/off device, press the Power/Control Button quickly 5 times. When powering on, device will vibrate 1 time, white LED lights will stay on for 3 seconds followed by temp/voltage indicator lights for 2 seconds that shows your prior selected setting

LED lights flash 3 times after chamber placement with different colors indicating what adapter/chamber has been attached:

- Dry Flower/Herb: Red
- Concentrate: Blue
- 510 Adapter: Green
- Battery Placement: White followed by installed adapter/chamber




Start burn cycle by inserting the concentrate or herbal chamber and double click the power on/off device button to cycle to the highest temperature setting




Take one short puff to begin heating process and immediately set device down to complete burn-off cycle

Once device vibrates 3 times for herbs/flower and 1 time for concentrate and turns off automatically, the burn-off cycle is complete



Once burn-off cycle is complete allow device to cool for at least 5 minutes before handling cleaned herbal chamber


After performing a burn-off session, choose your desired temperature. Take one short puff to activate heating—blinking LED lights will confirm it's warming up. Once the lights turn solid (about 60 seconds at any setting above 338°F with the flower chamber), take long, steady inhales to enjoy full terpene vapor.



CHAMBER USE


Dry Flower/Herb Chamber

Remove both parts of mouthpiece



Prepare Dry Flower/Herb by coarsely grinding. For convection to work the best, it should be loosely packed.

Loosely pack up to 0.3g of ground material into chamber.



Turn device on by clicking Power/Control Button quickly 5 times

Then place chamber into device by lining up dot on chamber with device Power/Control Button until you feel the magnetic click and see the **Red** lights


Re-attach both parts of mouthpiece



Click Power/Control button 2 times to cycle through temperature settings as follows to find the desired temperature




338°F




365°F




392°F



410°F





428°F



Take short puff through mouthpiece to start heating process: LED lights will blink during heating process

Mixturus can be cold started by taking puffs during heating process. Terpene flavors can be enjoyed after 60 seconds and then throughout your herbal session




Mixturus will vibrate and LEDs will turn solid when the Mixturus is fully heated and ready for use

Concentrate Chamber

Follow same process as Dry Flower/Herb chamber to insert Concentrate chamber

Fill concentrate chamber with up to 0.2g of concentrate of choice, and ensure it is touching the bottom plate. Replace mouthpiece.



1. Turn device on by clicking Power/Control Button quickly 5 times. Then insert the concentrate chamber into position and ensure you see the **Blue** lights.

Click Power/Control Button 2 times to cycle through temperatures as follows:




400°F




450°F





500°F



550°F



600°F





- Click Power/Control Button 3 times to preheat if airflow is restricted

Device will vibrate and LED lights will stop blinking when device is fully heated and ready for use

510 Thread Oil Cartridge Chamber

Turn device on by clicking Power/Control Button quickly 5 time




Remove mouthpiece in the same way as previous chambers, insert Cartridge Adapter

Screw chosen 510 thread cartridge into adapter



Insert adapter into device by lining up the dot on adapter to Power/Control button until you see **Green** lights




Replace only bottom half of mouthpiece


Click Power/Control Button 2 times to cycle through voltage settings to find desired voltage as follows




1.8V




2.2V



2.7V



3.2V




3.7V



3x

Click Power/Control Button 3 times to preheat if needed


Take long puffs by holding Power/Control Button for additional session strength or use Auto-draw without button for slightly less strength.



Auto-draw is activated by taking puffs without holding Power/Control Button after device recognizes cartridge

Tips and Tricks



Lower Temperatures/Voltages will produce more flavor but less visual vapor, higher temps/volts will produce more vapor but will have less flavor



Keep the herb chamber on, remove the top mouthpiece, and empty content while the device is warm. Refill with fresh herbs to continue your session seamlessly.




If using cotton filter, using the same multi tool bit, place pointed end into small hole in center of cotton filter, pick cotton filter out





To reuse the cotton filter, immerse it in isopropyl alcohol until it appears white, then let it dry completely. Use your fingers to reinsert the cotton filter into the small opening at the bottom of the top mouthpiece.

To protect pockets and the tool, replace pointed end of bit tool back down into larger end of tamp and screw on cap.





To install cotton filter into mouthpiece:



Unscrew cap to multi tool cover; cap acts as tamper

Remove pointed metal multi bit from inside tamp and place large end of multi bit tool inside opposite small end of the tamp creating a handle (it clicks into place)



Locate the small metal screen beneath the mouthpiece, use the bit tool's pointed end in the rubber seal's notch to lift it, then insert the cotton filter into the center hole below.




Dab essential oils straight onto filter parameter while in mouthpiece or on a tray. Place Cotton filter in top portion of mouthpiece can be infused with terpene/herbal oils for an aromatic flavor mix. **No more than 2 drops of oils should be added.**

Order more filters through RITE INNOVATIONS




MAINTENANCE/CLEANING

Make sure connection points on charging pad and device are clean and free from material




Regular cleaning of chambers between material/flavor transitions allows user to experience the purity of each material/flavor vs materials/flavors mixing. After each session it is recommended to clean your chamber.

DO NOT soak chambers in any liquid!
















Clean mouthpiece parts with alcohol cotton swabs







Entire Mouthpiece and parts are dishwasher safe in top rack of dishwasher, however if using cotton filter, it must be removed prior to putting into dishwasher



TROUBLESHOOTING

Issue	Solution
<p>Device won't turn on</p> 	<p>Make sure battery is installed correctly</p>  <p>fully charge battery.</p> 
<p>No vapor production</p>  	<p>Ensure mouthpiece is not clogged and air can pass through, replace cotton filter if oversaturated.</p>  <p>Use multi tool/brush to clear holes in metal screen or soak in isopropyl alcohol overnight</p> 

Issue	Solution
<p data-bbox="91 167 466 238">Device exterior feels too warm</p> 	<p data-bbox="533 167 839 238">Allow device to cool before touching</p> 
<p data-bbox="91 687 471 758">Top and Bottom yellow lights flash continuously</p>  <p data-bbox="91 1014 471 1049">OR yellow lights flash 5x</p>  <p data-bbox="339 1155 398 1199">5x</p>	<p data-bbox="533 687 854 829">Remove the battery, remove the chamber/adapter, re-insert the battery.</p>  <p data-bbox="533 979 932 1234">Clean the contact points on your chamber/adapter and the Mixturus. Re-attach the chamber/adapter. If issue persists, contact Rite Innovations.</p> 

Issue	Solution
<p>Yellow lights flash 3 times during herb chamber heat-up</p>  <p>3x</p>	<p>Fully charge battery or swap to a new, charged battery</p>
<p>All blue lights flash 5 times</p>  <p>5x</p>	<p>Clean the contact points on your chamber/adaptor and on the Mixturus. If issue persists, contact RITE INNOVATIONS for a solution</p> 
<p>All red lights flash 8 times</p>  <p>8x</p>	<p>Battery charge is too low, needs to be charged</p> 
<p>All red flashing lights persist with partial charge</p> 	<p>Continue allowing to charge fully before use and all lights will turn green. In some cases batteries may need to be reconditioned which could take 6 hours to fully charge. If red lights persist contact Rite Innovations.</p>

EXPLORING VAPABLE HERBS

There are many types of Dry Herbal material you can enjoy with the Mixturus.



Eucalyptus



MULLEIN



SAGE



CHAMOMILE



THYME

Precaution

Only use Dry Herbal material which has been tested by the FDA, EPO, or similar agency. Any other use can be potentially harmful.



Mixturus is not intended for use of tobacco/nicotine products

Suggested Dry Herb Temp Settings

Herb Name	Temperature Setting
Eucalyptus	130°C (266°F)
Hops	154°C (309°F)
Chamomile	190°C (374°F)
Lavender	130°C (266°F)
Lemon Balm	142°C (288°F)
Sage	190°C (374°F)
Thyme	190°C (374°F)
Mullein	154°C (309°F)
Rose Petal	190°C (374°F)
Peppermint	130°C (266°F)
Blue Lotus Flower	190°C (374°F)


WARRANTY/SERVICE

1-year warranty on device



1-month warranty on chambers

(additional battery and chambers/adaptor can only be purchased from RITE INNOVATIONS)





Designed in Benton Harbor Michigan
Assembled in China
www.riteinnovations.com

